AVIATOR Smart Watch

with additional silicone band

AVSW4218

AVIATOR

F SERIES

User Manual

Warranty
Your Aviator F Series smartwatch is made and tested to exacting standards. We warrant to the original consumer that the smartwatch will be free from defects in materials and workmanship under normal use for a period of two (2) years from date of purchase. During this period, the smartwatch will be repaired or replaced (at the sole discretion of Aviator F Series smartwatches) free of charge, if it proves to be defective in material or workmanship under normal use.This guarantee does not affect your consumer rights.

Water Resistance
Your Aviator F Series smartwatch is suitable for everyday use and can withstand perspiration, drops of water when washing the face and very small amounts of moisture in daily activities. Not suitable for showering, rainfall & any other water or water sport activities.

Service and Repairs under Guarantee
IMPORTANT-Not covered by Guarantee:
1. Batteries, straps and bracelets
2. Damage caused by accident, misuse, lack of care, natural aging, repairing or dissembling without authorization
3. Water penetration (see Water Resistance)
4. Damage caused by connection with equipment which is not compatible.
5. Damage caused by conditions mentioned in page 3 under "Charging Instructions", page 9 under "Know your device" and/ or page 10 under “Battery"

If your smartwatch requires attention under the terms of the guarantee, please email your Retailer’s Sales Receipt or Proof of Purchase, a photo of the completed Guarantee slip from this booklet (page 11 or 23), a photo of the back of the smartwatch, and a brief explanation of the fault, to our service centre at aviator@laserworldwideltd.com. Once we have verified your details and proof of purchase, we will provide instructions on how to proceed with your warranty claim.

Introduction - Thank you for choosing our product Aviator F Series smartwatch AVSW4218

Setting Up Your Aviator F Series Smartwatch AVSW4218

The first step is to download and install the AVIATOR Smart F Series App in your mobile from the QR code on your box, watch or manual & create an account to sync the information.

IMPORTANT! Before using the smartwatch, please peel off the protective transparent film as follows -

1) front of the smartwatch
2) back of the smartwatch

Charging Instructions

Charge your watch fully for the first time before use. Before every charge, clean the surface of the watch of any debris or foreign material to avoid interference in charging. Next, connect the back of the smartwatch to the magnetic side of the charger. After a few seconds, the display will light up and indicate the charging progress.

Important - 1) Do not use a USB charger other than the one provided with this Aviator Smartwatch to charge the smartwatch. Otherwise, the circuit and/or watch may be damaged, and the watch will not be charged. This will **void the warranty** of the smartwatch & the charger.

2) Do not charge any other device besides the Aviator smartwatch with this charging cable as it may cause a short circuit and result in damaging the charging cable, which will void its warranty.

Easy Switch Strap

The Aviator F series smartwatch AVSW4218 comes with an additional silicone band. This smartwatch contains two parts (watch body & strap). You can replace the strap by pressing the ear switch at the back of the strap towards the right or left.



Pairing

1) Power on - Press and hold the top button for 5 seconds until vibration.
2) Enable BT on your phone, then open the **Aviator Smart F Series** app > 3rd tab> Add Device
3) Select your Aviator smartwatch from the scanning list. Verify your device with the ID (XX:XX:XX:XX:XX:XX) and match it in your smartwatch Settings (Swipe down from the top of the dial display) ⚙ > About> Version
4) If a pairing prompt does not appear within 10-15 seconds, connect it manually via your phone's BT settings as follows-
   a) Go to phone settings> BT> Aviator4218> Pair/Allow.
   b) If not listed, activate it on your smartwatch > Control centre (swipe down from the top of the dial display), tap to change it to . The watch (Aviator4218) will now appear in your BT list. Select it to connect.
5) Pairing complete.

Smart Watch Features

Menu (Swipe right from the left of the dial display)

The main page of the menu will display the 5 most recently used features. Select ⋯ at the bottom right to go to the main menu.

The menu has an extensive range of features including activity (step counter), sleep, heart rate, phone, exercise, exercise records, flashlight, blood pressure, SpO2, weather, messages, camera, music, voice assistant, timer, alarm, stopwatch, world time, find phone, calculator, compass, barometer, and settings ⚙ which include display, (brightness, screen lock, watch face, menu view, quick view)vibrate & ring, DND, low power mode, phone (on/off, media audio, phone reset), Always on display (on/off, analog, digital, display period) system (restart, power off, reset), About (Version & App download/ QR code) and Languages.

Phone Calls (Swipe left from the right of the dial display)
Calls can be made & answered on the smartwatch. Turn this feature on/ off in the Control center (Swipe down from the top of the dial display) > Settings ⚙ > Phonel: on/ off. Alternatively, you can also press 📱 in the Control center to manage all audio control features like phone calls & music. If the calls won't connect, ensure the smartwatch is paired in your phone's BT settings. If issues persist, reset your smartwatch under Settings ⚙ > System, then pair again. Keep the watch close to your phone during setup and use.

Blood Pressure
Tap to start measuring your Blood pressure. The smartwatch & app can show the data of the last 7 times.

SpO2
Tap to start measuring your Blood Oxygen level. The smartwatch & app can show the data of the last 7 times.

Heart Rate
Tap to measure your current heart rate. For continuous all-day monitoring, enable this feature in the app >3rd tab> Others> Health, where you can also set the measurement frequency. Note: This feature significantly reduces battery life. To set a high heart rate alert, define your maximum BPM limit in the app>3rd tab> Others> Health> Heart Rate Warning

Activity (Step counter)
The smartwatch & app automatically tracks Steps taken. Scroll down for the number of steps, kcal, minutes, day & week-trend. Note – Movement stats reset at midnight.

Sleep
The smartwatch & app monitors the duration & quality of your sleep when you wear your device to bed. Note – Sleep stats record between 10pm & 8am and are reset to zero at 10pm.

Exercise & Exercise Records Choose from 110+ sports to track. For **GPS activities** like running and cycling, ensure you are outdoors with a clear sky view for satellite connection. Your last session appears on the main screen (1st tab). View all history and maps in the app's 2nd tab.

GPS Exercise Choose from 5 GPS modes. Ensure the GPS shortcut is on in the Shortcuts menu. Sync with the App and update EPO if red. For signal acquisition, be outdoors with a clear view. Wait for the "Start" button to turn green, or begin immediately.

Control center (Swipe downwards from the top of the dial display) The control center includes the date, sync indicator which turns grey when the app is disconnected, battery life icon, do not disturb (DND), battery saver, brightness, media audio: phone / watch , settings and GPS . *Settings include display, (brightness, screen lock, watch face, menu & quick view) vibrate & ring, DND, low power mode, phone (on/off, media audio, phone reset), system (restart, power off, reset), always on display, About (version & App download/ QR code) and Language.

Stopwatch Tap the screen control to start, pause or reset the stopwatch.

Music After connecting the device, control your phone music player remotely through the smartwatch. Turn this feature on/ off in the Control center (Swipe down from the top of the dial display) > Settings >Phone > Media Audio: on/ off. Alternatively, you can also press in the Control center to manage all audio control features like music & phone calls.

Camera Use your smartwatch as a remote to take photos with your paired smartphone. To set up, open the App > 3rd tab > Camera. Position your phone for the shot. Open the camera on your watch to capture. Ideal for group photos or hands-free shooting.

Messages Swipe up from the bottom of the dial to view notifications from WhatsApp, X, FB, IG, WeChat, messages, emails and more. Note: Sync with the app to view the last 8 notifications.

Voice Assistant
Press the screen to speak to your phone's voice assistant. The screen icon will change to indicate it's listening. Simple replies like weather updates, are spoken aloud through the smartwatch. Detailed responses, including photos, appear on your phone. This requires Phone Audio to be 'on' in your BT & smartwatch control settings for the speaker to work.

Time & Weather
Select your city and temperature format in the App> 3rd tab> Others> Weather. Once saved, your watch's time will update automatically, and current weather plus a 7-day forecast will appear in the Weather feature.

Reminders to move and to drink water
Receive vibration alerts at regular intervals to remind you to move and to drink water. Note: Turn these features on/off in the app> 3rd tab> Others> Health.

Find phone
Tap Find Phone on your watch to make your misplaced phone vibrate and sound an alarm. Tap again to stop. Note: BT must be enabled on your phone for this feature to work.

Compass
The digital compass will help guide you in the right direction. When asked, please calibrate the compass by following the onscreen instructions.

Barometer
The built-in barometer sensor measures atmospheric pressure and calculates your current altitude. Use this data to monitor weather trends and elevation changes.

SOS Emergency Help

1) To use this feature, turn it on in the 3rd tab -> others -> health→ SOS Emergency Help.
2) Next in the "Settings" of your phone, find & click the Emergency SOS, then add a contact under Emergency contacts.
3)The watch MUST be connected to BT and the turned on in the control centre.
4) In case of an emergency, press the top pusher repeatedly 5 times. Your phone will automatically call the emergency number listed in your country, as well as send an sms with your location to your emergency contact if you have assigned them.

World Time

Your watch can display the time of 6 different cities simultaneously. Add these cities of your choice in the App> 3rd tab > World Time.

Alarm

Set up to 8 alarms on the smartwatch or app. The device will ring & vibrate when the alarm goes off.

Personalize dials

Set a photo from your smartphone gallery as the default watch face via the App > 3rd tab > Watch Faces > Edit > swipe right until the end > Choose from album > Photos/ Collections > select image > √ . The download progress will show on your watch. Keep the watch connected to the app, close to your phone, and do not turn off any of your devices during transfer.

Customize dials

Edit the text, position, color, and pointer style on your dial. In the App > 3rd tab > Watch Faces > Edit > personalize the 4 widgets. Keep the watch connected to the app, close to your phone, and do not turn off any of your devices during transfer.

Cloud Dials

Download new dials from the cloud to refresh your watch style daily. Browse over 120 faces and apply your choice via the App > 3rd tab > Watch Faces > swipe right to the Face Gallery > + > select photo > Apply. Keep the watch connected to the app, near your phone, and do not turn off any of your devices during transfer.

KNOW YOUR DEVICE

1. Using in Wet Conditions - The smartwatch and its charger are sweat & splash resistant; and can withstand very small amounts of moisture in daily activities. **Do not wear** the smartwatch while showering, swimming, diving, scuba diving, surfing, in saunas, during in high-velocity sports, any water activities, in the rain or snow. Do not use the watch button when the device is wet.

2. Device Sensitivity - The smartwatch and its charger can be permanently damaged if they are:

- Dropped, bumped, or subjected to any impact.
- Exposed to liquids including water, rain, soap, shower gel, detergent, lotion, perfume, oil, or similar products.
- Used in high temperature, high humidity environments (e.g. hot baths, saunas hot springs, etc).
- Exposed to hot steam, smoke, or vapors (e.g. from heaters, grills, geysers, barbeques, machinery, water heaters, etc).

3. Heat Exposure Do not expose the watch and its charger to direct sunlight or intense heat. (e.g. from heaters, ovens, microwaves, etc). Smartwatches & their chargers, like all other electronic devices are designed to operate within a specific temperature range. Prolonged exposure to extreme hot or cold temperatures can cause overheating or freezing.

4. ⚠ Not suitable for children under 3 years. Small parts (detachable strap with small parts). **Choking hazard.**

IMPORTANT! Exposure of the smartwatch or charger to any of the conditions listed above may damage internal components and circuits, affecting their performance and safety. Such damage is irreparable and will **void the warranty.**

5. Quick View lets you see the time or phone notifications without touching the screen - just turn your wrist toward you. Turn this feature on/off either on your smartwatch> Control Centre (swipe downwards from the top of the watch face) > or in the App> 3rd tab> Others> Quick view.

6. Always on display - This feature allows you to keep your watch face visible at all times. You can choose between an analog or digital clock style, and set a specific display period. Turn this feature on/off on your smartwatch> Control Centre (swipe downwards from the top of the watch face)> Settings ⚙> Always on display. Note: Enabling this feature will increase battery drain.

BATTERY

> The battery percentage shown on your watch face is an estimate and updates in increments of 20% from 0 through 100%.

> Battery life varies depending on use similar to all battery operated electronic devices. Frequent use of GPS, notifications, and other power-intensive features will drain the battery faster.

> Do not use any USB charger other than the one provided with your Aviator Smartwatch. Using another charger may damage the device, prevent the battery from charging, and **void your warranty.**

ATTENTION!

> The smartwatch measurement results are for your reference only and are **not valid** for any medical purpose. Please follow your doctor's instructions and do not rely on the smartwatch for self-diagnosis or treatment.

> Some functions may vary from this manual depending on the software version installed on your smartwatch.

> We reserve the right to modify the contents of this manual without prior notice.

GENERAL SPECIFICATIONS

1. Environmental conditions

Operating temperature: 14°F to 122°F (-10°C to 50°C)·
Non-operating temperature: -4°F to 140°F (-20°C to 60°C)

2. Recycling & Disposal

It is the customer's responsibility to properly recycle and dispose off the smartwatch and its components. Do not dispose off the smartwatch with common household waste. It is electronic waste and should be taken to a local electronic equipment collection facility. For more information, please contact your local electronic waste management authority or the retailer where you purchased the product.

Service Centres

Aviator Watch S.A.
Chemin du val, 2 CH-2900,
Porrentruy, Switzerland.
Phone:+41 32 466 8015
https://www.aviatorfseries.com

NHP Hanse Travel Retail GmbH
www.hansetravelretail.com
Email: aviator@laserworldwideltd.com

For other languages please visit:
www.aviatorfseries.com/usermanuals

Purchase Details

Name: _____

_____

Date and Place of Purchase: _____

_____

_____

Address: _____

_____

_____

SIMPLIFIED EU/UK DECLARATION OF CONFORMITY

Laser Worldwide Limited hereby declares that the radio equipment type Aviator Gent's GPS Smart Watch AVSW4218 complies with Directives 2014/53/EU, (EU) 2015/863 and 2011/65/EU.

The full text of the EU Declaration of Conformity is available at the following web address: https://laserworldwideltd.com/compliance/smart-watches/

Importing UK Company:
JNS Brand Management Ltd.,
19th Floor, 1 Westfield Avenue, London,
England, E20 1HZ.

Manufacturer:
Laser Worldwide Limited,
Unit 1106, Car Po Commercial Building,
18-20 Lyndhurst Terrace, Central, Hong Kong.

Importing EU Company:
NHP Hanse Travel Retail GmbH
Kühnehöfe 1, 22761,
Hamburg, Germany.

GET IT ON
Google Play

Download on the
App Store

Made in China