



**AVIATOR**  
**F-SERIES**

## Contents

Pg. 1 .....	Contents
Pg. 2 .....	Warranty
Pg. 3 .....	Service & repairs under Guarantee
Pg. 4 .....	Water Resistance
Pg. 5-6 .....	Advice & care of your Timepiece
Pg. 7.....	Service Centres & Languages
Pg. 8 .....	Display Elements
Pg. 9 .....	Stopwatch hands position adjustment
Pg. 10 .....	Time & Date setting
Pg. 11 .....	Stopwatch
Pg. 12-13 .....	World-Time
Pg. 13 .....	Importer & Manufacturer Details
Pg. 14 .....	Purchase Details (for Warranty).



Your Aviator F Series timepiece is made and tested to exacting standards. We warrant to the original consumer that the watch will be free from defects in materials and workmanship under normal use for a period of two (2) years from date of purchase. During this period, the watch movement will be repaired or the watch will be replaced (at the sole discretion of Aviator F-Series watches) free of charge, if it proves to be defective in material or workmanship under normal use.

This guarantee does not affect your consumer rights.



## Service and Repairs under Guarantee

**IMPORTANT – Not covered by Guarantee**

1. Batteries, straps and bracelets
2. Damage caused by accident, misuse or lack of care
3. Water penetration (See page 4 Water Resistance)

If your timepiece requires attention under the terms of the guarantee then please post your timepiece together with the Retailers Sales receipt or Proof of Purchase, the completed Guarantee slip on the back cover of this booklet and with a brief explanation of the nature of the fault, by Registered Post or recorded delivery to your nearest service centre.



## Water Resistance

Your Aviator timepiece is water resistant to 3/5/10 atmospheres and is clearly marked with the static water pressure indicator (3ATM/5ATM/10ATM) on the caseback.

3ATM: Suitable for everyday use. Splash/rain resistant.

5ATM: Suitable for short periods in water and gentle swimming

10ATM: Suitable for normal swimming, no diving of any kind



## Advice and Care of Your Timepiece

Your Aviator timepiece is a precision instrument. Follow these instructions to get the best possible performance from your timepiece.

### Operating and Adjusting Your Timepiece

Your quartz analogue watch is powered by a battery which was inserted at the time of manufacture and will require periodic replacement. If your watch stops have the battery checked as soon as possible. A “dead” battery may cause serious damage to the movement if left inside too long.



## Advice and Care of Your Timepiece

New batteries can be supplied and fitted by most reputable High Street Jewellers or watchmakers and repair centres. Do not try to open the caseback yourself.

NB. The fitting of an incorrect battery could permanently damage the movement.

Quartz analogue timepieces DO NOT require winding.



## Service Centres

Aviator Watch S.A.

Chemin du val, 2

CH-2900, Porrentruy,

Switzerland.

Phone: +41 32 466 8015

Email: [fseries@aviatorwatch.ch](mailto:fseries@aviatorwatch.ch)

<https://www.aviatorfseries.com>

For other languages please visit:

<https://aviatorfseries.com/usermanuals>




NHP Hanse Distribution GmbH,

[www.hanse-distribution.com](http://www.hanse-distribution.com)

[service@hanse-distribution.com](mailto:service@hanse-distribution.com)



## Display Elements



## Stopwatch hands position adjustment

Before setting the time, be sure to check that the stopwatch hands are in the “0” position. If either of the stopwatch hands is not at the “0” position, reset them, following the procedure below:

1. Pull out the crown to second click.
2. Press “A” repeatedly to reset the stopwatch 1/10-seconds hand to the “0” position.
3. Press “B” repeatedly to reset the stopwatch seconds hand to the “0” position.
4. Push back the crown in to the normal position “0”.

*A: The hands move clockwise.*

*B: The hands move counterclockwise.*

## Time and Date Setting



### Unlocking the crown

1. First, turn the crown counter-clockwise until you no longer feel the threads turning.
2. Next, pull out the crown.

### Locking the crown

1. Push the crown back into the normal position ("0").
2. Turn the crown clockwise while pushing it tight until you no longer feel the threads turning.

### Date Change (1st click)

At crown position "1", turn the crown clockwise to set the date.

### Time setting (2nd click)

At crown position "2", turn the crown clockwise to set the time.

### IMPORTANT

- (a) Before setting the time, check that the stopwatch measurement is stopped.
- (b) Do not set the date between 9:00 p.m. and 1:00 a.m. otherwise the day may not change properly.
- (c) When the crown is at the second click position, do not press any push button. Otherwise, the stopwatch hands will move.

## Stopwatch



- The stopwatch can measure up to 60 minutes in one second increments.
- The measured time is indicated by the stopwatch hands which move independently of the center 3 hands (hour, minute & seconds).
- Before using the stopwatch, be sure to check that the crown is set at the normal position ("0") and that the stopwatch hands are reset to the "0" position.
- If the stopwatch hands are not at the "0" position when the stopwatch is reset, follow the procedure in page 9 "Stopwatch hands position adjustment."

### Standard measurement



### Accumulated elapsed time measurement



### Split time measurement




## World-Time



The city names of the world's major cities are displayed on this bezel. The combination of the city name on the bezel and the 24-hour marker on the inner ring lets you know the approximate time of each city.

Example: If you wish to know the time in Geneva while you are staying in Hong Kong. Supposing that the hour hand is pointing to the current hour in Hong Kong which is 2:00 p.m.:

1. Convert the current hour in Hong Kong to the 24-hour format. (2:00 p.m. to 14:00).
2. Turn the bezel until the city name Hong Kong points to "14" on the 24-hour marker. The hour in Geneva which is 7 o'clock in the morning (7:00 a.m.) can be obtained by reading the hour marker to which the city name Geneva corresponds.



24-hour marker (inner ring)



The same manner can be applied to read the time in any other city on the bezel. For example, the hour in Los Angeles can be read as 22:00 (10:00 p.m.)

### Remarks

- Daylight saving time - adjust the settings manually, before & after the daylight saving time period according to your time zone.
- Cities on the bezel may differ by model.

### Importing UK Company:

JNS Brand Management Ltd,  
1 Vicarage Lane, Stratford,  
London, England, E15 4HF.

**Manufacturer:** Laser Worldwide Limited,  
Unit 1106, 11th Floor, Car Po Commercial Building,  
18-20 Lyndhurst Terrace, Central, Hong Kong.

### Importing EU Company:

NHP Hanse Distribution GmbH,  
Kühnehöfe 1, 22761,  
Hamburg, Germany.





## Purchase Details

Name

---

---

---

Address

---

---

---

Date and Place of Purchase

---

---

---

---